



INSTRUCTION SHEET

Fibrofor[®] Diamond



Basic materials

Abide to the basic principles for a quality concrete according to standards EN 206.

Concrete formula

When adding Diamond there is no need to adjust grading curve, cement content, water addition or water/cement ratio. Normally the flow diameter will be reduced by the fibres and has to be adjusted by adding a plasticiser. Diamond fibres won't react with additives and they are alcaliresistant. For the recipes, the respective regional standards have to be taken into account.

Dosage

The recommended addition rate for structural concrete is normally 2 - 3 kg fibres / m³ concrete. Modifications of the addition rate can be found in the structural calculation.

Fiber addition in the concrete plant

The fibres can be put into the mixer directly or can be added by means of a dosage machine when the sand-gravel-mixture is put into the mixer. The bags are not water-soluble and must be removed.

If necessary the fibres can also be added to the concrete in the ready-mixed concrete lorry without the bag and have to be mixed in with the drum rotating at maximum speed.

Mixing time

At the concrete factory: The total mixing time with 2 kg Diamond per m³ concrete is around 180 sec., with 3 kg per m³ around 240 sec., depending on the mixer type and the concrete recipe. The fibres have to be distributed homogenously at the end of the mixing process.

Before discharging fresh concrete on site, let the drum of the concrete lorry rotate again at maximum speed for 1 to 2 minutes.

For mixing in the concrete lorry: 2 minutes additional mixing time at maximum rotation speed per m³ concrete (for example: 6 m³ content = at least 12 minutes additional mixing time).



Adding fibres can reduce the flow diameter of the concrete. By adding a plasticiser or optimizing the w/c-ratio the necessary consistency class can be reached.

INSTRUCTION SHEET

12/2022

Before pouring

- Check the fiber distribution visually.
- Make a flow table test or a slump test.

Pouring

- Abide to the standards of pouring/pumping concrete.

Possible surface finishing

- Level with a lath or machine.
- Manual rubbing of the surface.
- Finishing (smoothing) of the surface with a machine (trawelling).
- Finishing (smoothing) with hard grain with a machine.
- Concrete finishing with a broom.
- Coating and waterproofing.

Remarks for surface finishing

- **Leveling:** no particular measures are necessary.
- **Manual rubbing:** start early, because fibres concrete will harden quicker. (depending on concrete quality and temperature).
- **Trowelling:** start early, because fibres concrete will harden quicker. (depending on concrete quality and temperature).
- **Finishing of the surface with hard grain:** start early, because fibres concrete will harden quicker (depending on concrete quality and temperature).
- **Finishing with a broom:** use a broom with synthetic bristles and begin working when the surface is fresh.
- **Coatings and impregnations:** Prepare the mature surface by sand-blasting or shot peening – apply primer and top coat as recommended by the supplier.
- **Cutting joints:** Begin with cutting 24 - 30 hours after surface finishing at the latest.

Stripping time

As per EN 206. Since fibres concrete has an increased early strength, formwork can be stripped earlier, if the minimum compressive strength has been reached.

Curing

Begin with curing immediately after having finalized the surface finishing.

Applying a protection against evaporation is recommended.

Contec Fiber AG
Industriepark Vial 2
CH-7013 Domat/Ems
Switzerland
T +41 81 632 80 10
info@contecfiber.com
www.contecfiber.com

